





Prior to November 2008 many autoclave tape brands such as FisherBrand, 3M Comply, Propper, Shamrock, and VWR (Canada) contained Lead Levels that exceed the hazardous waste disposal limits. This means it needs to be collected as hazardous waste after use.

Check the inside of your autoclave tape if you are using any of the brands mentioned above or refer to an MSDS. Most autoclave tapes with stripes at an angle /// contains lead; if it has very faint text "AUTOCLAVE" most likely it is lead free.

Dispose your leaded autoclave tape as hazardous waste.

Collect used pieces or tape roll in a ziplock bag
Affix a hazardous waste sticker on the bag
Submit a HAZARDOUS WASTE pickup request
http://vesta.cumc.columbia.edu/ehs/wastepickup/

Replace lead-containing rolls of autoclave tape with a non-lead containing alternative below or thru your laboratory sales representative. Some examples of lead free autoclave tapes are.

Autoclave Indicator Tape , TimeMed Labeling (VWR-14217-334)
Fisherbrand Autoclave Tape Product # (15-999-100B)
VWR Autoclave Indicator tape (VWR-73390-064)
SPS Medical—Latex/Lead Free Steam Indicator Tape Product # (LF2-048)
Schein Dental — Latex /Lead Free Sterilization Tape Product # (1126361)

COLUMBIA UNIVERSITY
IN THE CITY OF NEW YORK
Environmental Health & Safety

For more information contact your <u>Laboratory Safety Officer</u>