

# BEFORE ENTERING AN AFFECTED SPACE

- Turn on the device outside of the space where the alarm is active.
- Confirm the device is functioning and showing stable readings.
- Crack door and use sensor to check oxygen levels. Only proceed with entry if the reading is within normal range.
  - Normal range = 20.8% - 21%

*Note: Alarm thresholds:  $\leq 19.5\%$  (low) and  $\geq 23.5\%$  (high)*

## SENSOR MAINTENANCE

### Charging & Battery

The sensor is rechargeable and provides up to 120 hours of runtime on a full charge. A real-time battery indicator is shown on the display, and a low-battery alert activates when the charge is low. The manufacturer specifies a full charge time of approximately 4 hours.

### How to Turn On / Turn Off

Turn On - Press and hold the power button for ~2–3 seconds until display activates.

Turn Off - Press and hold the same button until shutdown display activates. Press the left button to shut off and press the right button to cancel shutdown.